NADP-NTN PFAS Site: Quarterly QC Field Blanking and Field Spiking Procedures

<u>General</u>

- Required supplies will be provided quarterly
- Please wear PFAS PPE (provided Tyvek jacket and **NTN vinyl** gloves) throughout the QC procedures
- Please perform the "Blank" procedure and then the "Spike" procedure, at the field site, on any convenient day within two weeks of receiving the supplies.
- Please fill out the corresponding chain of custody form for the three samples and send it back in the bag that it came in.
- SAVE box and packing materials for return shipment.
- Questions: Call NADP Toll Free: 1-800-952-7353

Blank Procedure

- Special supplies needed (provided by PFAS Research Center)
 - Full 1 L bottle labeled **SOURCE WATER**
 - Empty 1 L bottle labeled **FIELD BLANK**
- Prepare a bagged NTN bucket following standard protocol
- Pour half (500 ml) of the 1000 mL SOURCE WATER into the newly prepared bagged bucket
- Gently swirl the bagged bucket, loosely cover, and let sit for <u>30 minutes</u>
 - Pour the 500 mL of water from the bucket into the provided 1 L bottle labeled "FIELD BLANK"
 - Remove, fold, and place the bucket bag into the provided 4" x 15" zip-lock bag Label bag with "FIELD BLANK"

Spike Procedure

- Special supplies needed (provided by PFAS Research Center)
 - o 500 mL of high purity PFAS-free reagent water in 1L bottle labeled "FIELD SPIKE"
 - Small vial (2 mL) containing PFAS spike (labeled *PFAS spike solution*)
- Prepare a bagged NTN bucket following standard protocol
- Pour the full 500 ml from the **FIELD SPIKE** bottle into the newly prepared bagged bucket
- Pour the full contents of *PFAS spike solution* (2 ml vial) into the water in the bagged bucket
- Gently swirl the bucket, loosely cover, and let sit for <u>30 minutes</u>
 - Pour the 500 mL of spiked water back into the 1 L bottle labeled "FIELD SPIKE"
 - Remove, fold, and place the bucket bag into the provided 4" x 15" zip-lock bag Label bag "FIELD SPIKE"

<u>Shipment</u>

- Send back the FIELD BLANK sample (along with the folded bucket bag)
- Send back the FIELD SPIKE sample (along with the folded bucket bag)
- Send back the remaining **SOURCE WATER**
- Place all three bottles and two folded bags in the box that they came in for shipping

NADP – 2023 – PFAS Field QC – Bag Sites