MDN Sample Change-out, N-CON Single-Chimney Collector

Items needed:

- MDN Observer Form (MOF), as started the previous week
- MOF, for current week's sample
- shipping cooler for deployed sample bottle and sample train (previous week's sample)
- shipping cooler for sample and sample train to be deployed (current week's sample)
- fresh (< 6 months old) Reverse Osmosis (RO) water in a plastic squeeze bottle
- Formula 409 cleaner*
- paper towels
- lab wipes
- small, flat-blade screw driver

Precautions:

MDN samples are analyzed for mercury in the parts per <u>trillion</u> (ppt) range. Use care when handling the sample bottle and glassware to avoid contaminating the sample inadvertently.

Upon receipt of the cooler box, inspect the contents of the shipping cooler containing the glassware and sample bottle that will be deployed. Report any problems (e.g., broken glassware, missing glassware, bottle leakage) to the site liaison (see **Contact Information** section of this document). Memos detailing new information from the analytical laboratory may be included in the cooler as well.

Instructions:

- 1. Approach the collector from the direction that faces into the wind (downwind). This will help prevent accidental contamination of the sample. If there is snow or ice on the collector lid, brush it off before proceeding.
- 2. Complete block 2 (**Observer OFF**) of the MOF for the sample to be retrieved. Enter the name of the Observer who is removing the sample.
- 3. Observe condition of the equipment and the site. List any unusual conditions in block 9 (**Remarks**) of the MDN Observer Form (MOF). See the Appendix to this document for a sample MOF.





* **Disclaimer:** Use of a trade or manufacturer's name does not constitute an endorsement by the University of Wisconsin, the Wisconsin State Laboratory of Hygiene, the National Atmospheric Deposition Program, or project sponsors.

9. REMARKS	For example: equipment malfunction, extreme weather conditions, contamination, farming, burning, logging, leakage, etc.

4. Open the door to the collector. In block 6 (**Enclosure Temperature**) of the MOF, record the minimum and maximum temperatures from the min/max thermometer located inside the collector. Circle either °F or °C.

	RFLOW eck one)	YES NO 2 1						
Amo	unt of Overf	low						
	■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■							
ENCL	OSURE T							
ENCL MAX	OSURE T		e one)					

5. Using a small, flat-blade screwdriver, adjust the thermostat to help maintain the minimum and maximum temperatures inside the enclosure between 40 and 100°F (4 to 38°C). Consider the expected weather conditions for the next week when adjusting the thermostat.



Retrieving the deployed sample bottle.

6. Position the shipping cooler for the deployed sample bottle near the collector so it may be accessed easily.

Wisconsin State Laboratory of Hygiene NADP Program Office Revision Date: 9/1/2019



7. Trigger the sensor by waving fingers through the detection area of the optical sensor. Turn off power to the collector when the collector lid is in the fully open position.



8. With one hand, grasp and lift the thistle tube out of the sample bottle. With the other hand, grasp the funnel and lift the sample train out of the chimney. Set the sample train aside in a secure location.

Wisconsin State Laboratory of Hygiene NADP Program Office Revision Date: 9/1/2019



- 9. Put on a pair of clean gloves. Retrieve the sample bottle cap from the zip lock bag and cap the deployed sample bottle. Avoid touching the interior surface of the bottle cap.
- 10. Leave the capped sample bottle inside the collector while re-packing the thistle tube and funnel in its shipping cooler. Retrieve the used sample train. Remove the blue clip that holds the funnel and thistle tube together and set it inside the collector to be re-used. Separate the funnel and thistle tube, returning each to its zip lock bag, and then to the shipping cooler.
- 11. Verify the ID of the sample bottle with the value listed in block 3 (**Bottle**) of the MOF. Enter the OFF Date and Time, i.e., the date and time the sample was collected. The Date is expressed in the form MMDDYY. Time is expressed based on a 24-hr clock.



12. Hold the bottle to the light and inspect the sample for visible contamination. Indicate in block 5 (Sample Conditions) of the MOF whether any of the listed contaminants are present in the sample. Check the appropriate box for item #6 in block 5 (Sample Conditions) to indicate whether the sample spilled or was otherwise compromised while handling. Describe any problems in block 9 (Remarks).

5. SAMPLE CONDITION	YES NO	YES NO	YES NO
Check type of contamination for each	² ¹ 1. Bird droppings	² 3. Soot/ash/dirt particles	² 5. Leaves/twigs/pollen/plant matter
sample . Describe all contamination in	² ¹ 2. Cloudy or discolored	² ¹ 4. Insects/animal matter	² ¹ 6. Handling contamination
Block 9, including any not listed here.			

- 13. Place the sample bottle in its zip lock bag, seal the bag, and return the sample bottle to its original shipping cooler.
- 14. Using a graduated cylinder, measure the volume of any liquid in the overflow container. Record this value in block 6 (**Overflow**) of the MOF. Dispose of the liquid after measuring. Do <u>NOT</u> pour liquid from the overflow container into the sample bottle. Doing so will invalidate the sample.

(Che	RFLOW eck one) int of Overf	YES NO		
		•	mL	J
ENCL	OSURE T	EMPERA	TURE	
		· ·		
MAX			le one) °C	

15. Close the cooler for the newly retrieved sample, and move it out of the way.

Cleaning the collector.

16. Spray Formula 409 cleaner onto a paper towel. Use the paper towel to clean the collector surfaces. Start by cleaning the white, plastic chimney caps, and work down toward the body of the collector.



17. Put on a clean pair of gloves. Moisten a lab wipe with RO water. Clean the underside of the collector lid, e.g., the surface of the lid pad.



18. Verify correct operation of equipment (sensor, motorbox, and raingage). Complete block 4 (**Site Operations**) of the MOF. Inspect the lid pad for damage. Request a new lid pad if needed. Indicate if the raingage has been winterized, and the date and time antifreeze was added to the raingage. Include additional comments in block 9 (**Remarks**).

4. S	ITE O	PER	ATIONS Check YES, NO, or U (Unable to determine) for each sample. If NO or U for Item 1 or 2, describe in Block 9 and call NADP Site Support 1-800-952-7353
YES 2 2 2 2 YES 2	NO U 1 0 1 0 1 0 1 0 1 1 1 0 1 1		 The collector sensor heater and motor box operated properly. Lid is in correct position Raingage operated properly during the week. Collector opened and closed at least once during the week, other than for testing. Raingage in winterized state during sampling period (antifreeze in bucket).
2	1		5. Fresh antifreeze added during sampling period? Date Time

Deploying new sample train and bottle.

- 19. Position the shipping cooler with the glassware to be deployed so it may be accessed easily. Switch to the MOF for the sample to be deployed.
- 20. Complete block 1 (Site) of the MOF for the sample to be deployed. This includes:
 - a. the name of the Site,
 - b. the 4 character ID of the Site (e.g.,WI06).

1. SITE]
Name		SITE	ID	

21. Inspect the zip lock bag containing the new sample bottle. In block 9 (**Remarks**) of the MOF indicate any damage to the sample bottle, and any leakage that may have occurred during shipment from the HAL to the site. In block 3 (**Collection**) of the MOF record the ID of the new sample bottle and the Box ID. The letter for the box ID can be found on the inside flaps of the box (i.e. WI06-A).

- 22. Put on a pair of clean gloves. Remove the sample bottle from its zip lock bag, place the sample bottle in the overflow container inside the collector, and loosen (but do not remove) the cap.
- 23. Open the zip lock bags that contain the funnel and the thistle tube, but leave them inside the bags. Connect the thistle tube to the funnel, and secure them with the blue clip that was set aside in Step 10.



- 24. Remove the bag covering the thistle tube.
- 25. While placing the thistle tube and funnel into the chimney of the collector, remove the cap from the sample bottle. The end of the thistle tube should extend into the sample bottle. Store the bottle cap in the zip lock bag that contained the sample bottle. Seal the bag to prevent accidental contamination.
- 26. Raise (or lower) the bottle jack so the lip of the funnel is at the top of the chimney cap and so the bulb of the thistle tube forms a seal with the mouth of the sample bottle.



27. Pull the funnel bag so it just covers the funnel.



- 28. Turn the power back on to the collector. This will cause the collector to close. As the collector lid approaches the funnel, pull the bag from the funnel <u>gently</u>.
- 29. Reset/clear the min/max thermometer. For an analog thermometer, turn the knob at the bottom of the thermometer. For a digital thermometer, push the "Clear" button while displaying the maximum temperature, and then again while displaying the minimum temperature.



- 30. Close and secure the door to the collector.
- 31. Complete the ON portion of block 3 (**Collection**) of the MOF to include the Date and Time that the sample bottle was deployed. Indicated if the time is Daylight Saving Time.



32. Store the MOF for use next week. Switch to the MOF for the previous week's sample, the sample that will be shipped for analysis.

Incorporating data from raingage.

33. Complete block 7 (**Precipitation Record**) of the MOF to include the daily precipitation values, and the type of precipitation (i.e., rain, snow, mixed, unknown) for each day with

precipitation. Refer to the appropriate SOP for downloading data from the electronic raingage. Record the date and time the electronic raingage data was downloaded. Raingage data should be sent to nadp-precip@slh.wisc.edu or uploaded to http://nadp.slh.wisc.edu/upload/ppt each week, regardless if there was precipitation or not.

7. PRECIPITATION RECORD											Al	l sit	tes	тι	ıst	circ	cle I	Pre	eci	pita	atic	on	Тур)e															
											R – Rain Only (Includes Hail) S – Snow Only M – Mixt													Mixture U – Unknown															
<u>-</u>			ON			TUE				WE					RS			FR				SA				SL				MO			T	JE	S		W	ED	
Type circle one →	R	S	Μ	U	R	S	Μ	U	R	S	Μ	U	R	S	М	U	R	S	М	U	R	S	Μ	U	R	S	Μ	U	R	S	М	U	RS	5 I	ΝU	R	S	Μ	U
Amount Inches →										•				•				•												•				•					
circle one		۲Z	Γ N	١M	Z	ĽΤ	Ν	/M	Z	Υ	M	IM	Z	Т	Μ	IM	Z	: т	Ν	٨N	Z	: T	T N	ЛМ	Z	T	Ν	1M	Z	Т	Ν	1M	Z	Т	ΜN	L	Z 1	N	1M
												Z	– Ze	ero			Т-	Tra	ce	(Ci	rcle	Ту	pe)			MM	- N	lissi	ng		_	_		_					
Data down	Data downloaded from raingage on : DateTime																																						
E gogo site		DIC			hm	it ve	r		otro	nio	roi		<i>a a</i>	dat		~m	nthu	off	ord	ohir	nin		~m	nlo					То	tal I	Raiı	nga	ge D	eptl	n (inc	hes	5)		
E-gage site Email data																										pt													

34. In block 8 (Supplies) of the MOF, circle any supplies that are needed.

8. SUPPLIES Circle if needed,	until received.
Gloves (S, M, L)	Field forms
Sample bottles	Funnel
Dry side bags	Thistle
Air filter	Lid seal pad
RO water	Packing tape
Site ID Barcode la	bels

- 35. Remove the pink copy from the MOF and store it with the site's records. Place the white copy of the MOF in the cooler containing the glassware and sample bottle from the previous week.
- 36. Tape the cooler shipping box containing the glassware, sample bottle, and MOF from the previous week and ship it to the HAL for analysis. It is not necessary to tape the cooler if it is shipped back in the box.
- 37. Store the cooler for the (new) current week for use next week.

Contact Information.

Please contact the NADP site liaison at 800-952-7353 or mdn@slh.wisc.edu if you have any questions, or if any problems are encountered. The site liaison can:

- help troubleshoot equipment problems,
- order replacement parts,
- explain the MOF, and
- explain the steps in this manual in greater detail.

Appendix – Sample MDN Observer Form (MOF)

-

Place barcode sticker here	MERCURY DEPOSITION NETWORK MDN OBSERVER FORM (MOF) Send completed form with each sample to: NADP Sample Receiving, 465 Henry Mall, Madison, WI 53706 Problems? Call NADP Site Support at 1-800-952-7353 e-mail: mdn@slh.wisc.edu
1. SITE Name	SITE ID 2. OBSERVER (OFF) Initials
3. COLLECTION BOTTLE ID Date ON DAY YR OFF DAY	A B C D (circle one) 4. SITE OPERATIONS Check YES, NO, or U (Unable to determine) for each sample. If NO or U for litem 1 or 2, describe in Block 9 and call NADP Site Support 1-800-952-7353 BOX ID Time 1 1 0 0001-2400 2 1 0 2 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 2 1 0 4. Raingage in winterized state during sampling period? Date
5. SAMPLE CONDITION Check type of contamination for eau sample . Describe all contaminatio Block 9, including any not listed her	nin 2 1 2. Cloudy or discolored 2 1 4. Insects/animal matter 2 1 6. Handling contamination
6. OVERFLOW YES NO (Check one) Amount of Overflow mL	7. PRECIPITATION RECORD All sites must circle Precipitation Type R - Rain Only (Includes Hail) S - Snow Only M - Mixture U - Unknown Type circle one → MON TUES WED THURS FRI SAT SUN MON TUES WED
ENCLOSURE TEMPERATURE	Amount Inches
8. SUPPLIES Circle if needed, until received.	E-gage sites: Please submit your electronic raingage data promptly after shipping sample. Email data to: nadp-precip@slh.wisc.edu or upload at http://nadp.slh.wisc.edu/upload/ppt
Gloves (S, M, L) Field forms Sample bottles Funnel Dry side bags Thistle Air filter Lid seal pad RO water Packing tape Site ID Barcode labels	9. REMARKS For example: equipment malfunction, extreme weather conditions, contamination, farming, burning, logging, leakage, etc.

Questions? Contact NADP Site Support 1-800-952-7353

Page 11 of 11