

Items needed:

- replacement grid sensor
- medium-sized, straight blade screwdriver
- medium-sized, Phillips head screwdriver
- Field Observer Report Form (FORF) for current week's sample

Instructions:

1. Disconnect the sensor from the motorbox by unscrewing the connector.



2. Unscrew the four screws securing the sensor to the frame of the collector. Be careful not to drop or misplace the screws as they will be re-used with the replacement sensor.



3. Remove the old sensor and set aside for return to the NADP Network Equipment Depot (NED).

Wisconsin State Laboratory of Hygiene NADP Program Office Revision Date: 1/8/2019


4. Retrieve the new sensor. Thread its cable though the hole in the collector body, and secure the sensor using the 4 screws that were removed in a previous step.



5. Note the slot in the connector attached to the sensor cable. Align the sensor connector with the corresponding motorbox connector. Tighten the connector to the motorbox.



6. Record comment and date in Block 10 (**Remarks**) of the Field Observer Report Form (FORF).



7. Return the old sensor to the NED. Include a note describing the problem with the sensor.

NADP Network Equipment Depot Wisconsin State Laboratory of Hygiene 465 Henry Mall Madison, WI 53706