

PFAS-Compatible Lid Seal Bag Replacement Instructions

Summary: Every 3 months, or more frequently if needed, remove the existing bag covering the PFAS-compatible lid seal and replace with a new 18x16" bag.

1. Remove the lid seal from your collector. See instructions on the NADP website for replacing the lid seal for your specific collector if needed
 - a. NCON collector: https://nadp.slh.wisc.edu/wp-content/uploads/2021/09/NTN-2111_Lid_Seal_Changeout_NCON_v_2-0.pdf
 - b. ACM collector: https://nadp.slh.wisc.edu/wp-content/uploads/2021/09/NTN-2102_Lid_Seal_Changeout_ACM_v_2-0.pdf
2. Remove the old Ziploc bag and discard.
3. With gloves on, place the lid seal into a new Ziploc bag, express the air and seal the bag
4. Fold the excess of the bag to the back of the lid seal to form a smooth surface on the front of the lid seal pad.
5. Place the lid seal back on the collector. See instructions on the NADP website for replacing the lid seal for your specific collector if needed (See links in step 1).